

ALVA AIR

50cm FLOOR FAN

ACS210 Chrome | ACS210B Black



- PLEASE READ THIS MANUAL CAREFULLY BEFORE USE AND ALWAYS OPERATE THIS PRODUCT ACCORDING TO THE INSTRUCTIONS
- RETAIN THIS MANUAL FOR FUTURE REFERENCE
- IT IS ILLEGAL AND DANGEROUS TO CHANGE OR MODIFY ANY PART OF THIS APPLIANCE

Manufactured for
and distributed by:

ALVA AIR

A division of Stingray Accessory Manufacturers (Pty) Ltd | P.O. Box 30014, Tokai, 7966
+27 21 442 1540 | info@stingray.co.za | www.alva.co.za
TOLL FREE NUMBER: 086 100 ALVA (2582)

IMPORTANT SAFETY INFORMATION

- Please read these instructions carefully before using your Floor Fan. The operator must understand all safety requirements as detailed in this manual before using the unit.
- The manufacturer's warranty may be voided by incorrect use of this product. If you have any queries regarding these instructions, contact your local dealer for clarification before using your Floor Fan.
- Always remove unit from all packaging materials prior to use.
- Failure to follow the manual's instructions could result in damage or serious injury.
- When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury, these basic safety precautions should always be followed.
- This product is intended for general domestic use to cool rooms and is not intended for use in windows.
- Do not use the product for any other purpose.
- Keep the product out of the reach of children and pets. This product is not intended for use by children.
- Do not leave the product unattended while it is in use, especially when children are present. Always unplug the product from the electrical outlet when it is not in use.
- Always operate the product on a flat, level, steady and stable surface to avoid it falling over.
- Do not hang or wall-mount the product.
- Do not place the product in or near an open window. Rain, snow, and other weather elements may create an electrical hazard.
- Keep the power cord and product away from sharp edges and heated surfaces.
- Always unplug the product from the electrical outlet when cleaning it.


Thank you for your purchase of this Floor Fan. Please read these instructions carefully before use and keep them in a safe place, for future reference.



**WARNING:
TO AVOID THE RISK
OF ELECTRICAL
SHOCK, ALWAYS
MAKE SURE THE
PRODUCT IS UN-
PLUGGED FROM
THE ELECTRICAL
OUTLET BEFORE
ASSEMBLING,
DISASSEMBLING,
RELOCATING,
SERVICING, OR
CLEANING.**

For indoor use only.

- Do not plug/unplug the product into/from the electrical outlet with a wet hand. Never insert fingers or any other object through the fan guards. Never drop or insert objects into any opening of the product.
- Do not attempt to open any part of the motor housing, as a risk of electrical shock may exist.
- Never operate the product without the fan guards in place, as serious personal injury may result. Plug the product into a standard outlet.
- Do not allow the power cord to hang (i.e., over the edge of a table or counter) where it may be tripped over or pulled.
- Do not operate product if the power cord is cut, damaged, or if the wires are exposed. Contact 086 100 ALVA (2582) or an Authorised Service agent to replace the power cord.
- Do not immerse or expose the motor housing, power cord, or plug to water or other liquids. Disconnect the plug (do not pull on the power cord) from the electrical outlet.
- Do not put any stress on the power cord where it connects to the product, as the power cord could fray and break.
- Do not operate the product if it has a damaged power cord or plug, malfunctions, is dropped, or damaged. This product has no user-serviceable parts.
- Do not attempt to examine or repair this product yourself. Qualified service personnel should perform any servicing. This product is intended for indoor, non-commercial, non-industrial, household use only.
- Do not use outdoors. This appliance is not intended for use by persons(including children) with reduced physical,sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.



To remove from the socket pull on the
plug, not the electrical cord

WARRANTY

PLEASE RETAIN YOUR PROOF OF PURCHASE FOR WARRANTY CLAIMS.

ALVA warrants this appliance to be free of defects in material and quality for a period of 12 months from date of original purchase. This warranty covers the intended use of this appliance – within a domestic setting and not for commercial or industrial purposes. Any damage caused by willful abuse, tampering, modification or unauthorized repair will not be warranted.

Please retain all packaging material, as items returned without original packaging material may be subject to a withholding fee. Where this appliance is found to be defective, damaged, broken, or does not work correctly for the intended purpose, you must return the appliance to the retailer from where it was purchased.

The warranty will only be effected with valid proof of purchase. Failure to provide the proof of purchase will most likely result in the repair or service required being chargeable.

If you have any questions while setting up or using this Floor Fan, please visit www.alva.co.za or call 086 100 ALVA (2582) or e-mail info@stingray.co.za

GENERAL INFORMATION

Before using this Floor Fan, please read through this manual and make sure you understand everything. If you are not sure, call **086 100 ALVA (2582)** or visit www.alva.co.za for help.

Reading and understanding this manual should give you a good indication of what to expect from your Floor Fan.

Always keep your proof of purchase. Keep these instructions for future use.

If you lose this copy, you can obtain a new copy from your dealer or online at www.alva.co.za

INDEX

| | |
|--------------------------|---|
| PARTS LIST | 2 |
| OPERATING THE FAN | 2 |
| SPEED FUNCTION | 2 |
| TILT FUNCTION | 3 |
| CABLE STORAGE | 3 |
| CLEANING AND MAINTENANCE | 3 |
| DISPOSAL | 4 |
| TROUBLE SHOOTING | 5 |
| SPECIFICATIONS | 5 |
| AFTER SALES SERVICE | 5 |

KEY

Notes marked with the following:



Contain important information.


Notes marked with the following:



Contain cautions and warnings.

PARTS LIST

Your Floor Fan has been packaged assembled, ready for immediate use.



OPERATING THE FAN

This Floor Fan is for domestic use, it is not intended for industrial or commercial use. Your Floor Fan is safe and easy to use.

Place the fan on a flat, level surface and ensure it is stable.

Put the plug in the wall socket, making sure the power cable is not taut and not in a walkway where it can be tripped over.

- **SPEED FUNCTION**

This Floor Fan has 3 speeds for your comfort and convenience

- 1 - Low speed
- 2 - Medium speed
- 3 - High speed

0 - Off button to stop the fan working



- **TILT ADJUSTMENT**

This fan can tilt through >90°

Hold the fan by the Rear Guard handle and tilt to the desired angle.

The fan head will automatically stay at the angle chosen.

- **CABLE STORAGE**

For your convience when not using the fan, the power cord can be wrapped around the metal hooks on the Rear Guard.



CLEANING AND MAINTENANCE

- The appliance, the power cord and the power plug must not be immersed in water or other liquids when you are cleaning them. Clean them with a dry cloth.
- If it is very dirty, the outside of the appliance can be wiped carefully with a moist cloth and then dried carefully. Make sure that no moisture penetrates into the interior of the appliance.
- Do not use any harsh cleaners, steel brushes, scouring powder or other hard objects to clean the appliance as these can cause scratches on the surfaces.
- Clean the appliance regularly.
- Never use solvents, benzene or oil-based cleaners as these can damage the housing.
- Re-tighten visible screw connections on the appliance regularly in order to ensure that the device is functioning properly.



Before cleaning the fan always remove the plug from the power socket to prevent injury or electric shock.

DISPOSAL

Used electric household devices

1. If you do require to use your electrical appliance any longer, dispose of it at a recycling depot for used electric appliances.
2. Used electric devices must not be disposed of with normal household rubbish.



Further disposal instructions:

1. Return the electrical appliance in such a condition that its later re-use or recycling is not adversely affected.
2. If applicable, batteries must be removed in advance and the destruction of parts which contain fluids must be avoided.
3. Electrical appliances can contain harmful substances. Improper handling or damage to the appliance can lead to health problems or water or ground contamination, when the appliance is recycled later.

TROUBLE SHOOTING



Should you experience problems with this Floor Fan, carry out the necessary checks as per the Trouble Shooting Guide.

SPECIFICATIONS

| | |
|---|------------------|
| Model | ACS210 - ACS210B |
| Description | 50cm Floor Fan |
| Voltage | 220-240V ~ 50Hz |
| Input Power | 120W |
| Any modification to the Floor Fan may cause injury or property damage. | |
| Any modification to the Floor Fan will invalidate the warranty on this appliance. | |

AFTER SALES SERVICE

MANUFACTURED FOR AND DISTRIBUTED BY
Alva Air, a division of Stingray Accessory Manufacturers
(Pty) Ltd.
P.O. Box 30014
Tokai, 7966
Tel: 021 442 1540
E-mail: info@stingray.co.za
www.alva.co.za
 www.facebook.com/AlvaGas
TOLL FREE NUMBER
086 100 ALVA (2582)